



User Manual



Maxima 3PH UR 10-20kVA

Uninterruptible Power Supply (UPS)



SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS. This manual contains important instructions that should be followed during installation and maintenance of the UPS and batteries.

The UPS that are covered in this manual are intended for installation in an environment within 0 to 50°C, free of conductive contaminant.

Special symbols



RISK OF ELECTRIC SHOCK - Observe the warning associated with the risk of electric shock symbol.



Important instructions that must always be followed.



EU separate collection and lead content mark for lead acid batteries. Indicates that the battery must not be disposed of to the normal household waste but be separately collected and recycled.

Pb



EU separate collection mark for waste electrical and electronic equipment (WEEE). Indicates that the item must not be disposed of to the normal household waste but be separately collected and recycled.



Information, advice, help.



Refer to the user manual.

Safety of persons

- RISK OF VOLTAGE BACKFEED. The system has its own power source (the battery). Isolate the UPS and check for hazardous voltage upstream and downstream during lockout-tagout operation. Terminal blocks may be energized even if the system is disconnected from the AC power source.
- Dangerous voltage levels are present within the system. It should be opened exclusively by qualified service personnel.
- The system must be properly grounded.
- The battery supplied with the system contains small amounts of toxic materials. To avoid accidents, the directives listed below must be observed:
 - Servicing of batteries should be performed or supervised by personnel knowledgeable about batteries and the required precautions.
 - When replacing batteries, replace with the same type and number of batteries or battery packs.
 - Do not dispose of batteries in a fire. The batteries may explode.
 - Batteries constitute a danger (electrical shock, burns). The short-circuit current may be very high.
- Precautions must be taken for all handling:
 - Wear rubber gloves and boots.
 - Do not lay tools or metal parts on top of batteries.
 - Disconnect charging source prior to connecting or disconnecting battery terminals.
 - Determine if battery is inadvertently grounded. If inadvertently grounded, remove source from ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock can be reduced if such grounds are removed during installation and maintenance (applicable to equipment and remote battery supplies not having a grounded supply circuit).

Product safety

- The UPS connection instructions and operation described in the manual must be followed in the indicated order.
- UPS enclosure IP rating IP20.
- CAUTION - To reduce the risk of fire, the unit connects only to a circuit provided with branch circuit overcurrent protection.
- The upstream circuit breaker for Normal AC/Bypass AC must be easily accessible. The unit can be disconnected from AC power source by opening this circuit breaker.

- An additional AC contactor is used for back feed protection and must comply with IEC/EN 62040-1 (the creep age and clearance distances shall meet the basic insulation requirements for pollution degree 2).
- Disconnection and overcurrent protection devices shall be provided by others for permanently connected AC input (Normal AC/Bypass AC) and AC output circuits.
- Check that the indications on the rating plate correspond to your AC powered system and to the actual electrical consumption of all the equipment to be connected to the system.
- For PLUGGABLE EQUIPMENT, the socket-outlet shall be installed near the equipment and shall be easily accessible.
- Never install the system near liquids or in an excessively damp environment.
- Never let a foreign body penetrate inside the system.
- Never block the ventilation grates of the system.
- Never expose the system to direct sunlight or source of heat.
- If the system must be stored prior to installation, storage must be in a dry place.
- The admissible storage temperature range is -25°C to $+55^{\circ}\text{C}$ without battery (-15°C to $+40^{\circ}\text{C}$ with battery).
- TN-S/IT/TN-C/TT of electrical supply system may be connected by UPS.
- This UPS may be provided with a maximum of 6 extension battery cabinets or equivalent.

Special precautions

- The unit is heavy: wear safety shoes and use vacuum lifter preferentially for handling operations.
- All handling operations will require at least two people (unpacking, lifting, installation in rack system).
- Before and after the installation, if the UPS remains de-energized for a long period, the UPS must be energized for a period of 24 hours, at least once every 6 months (for a normal storage temperature less than 25°C). This charges the battery, thus avoiding possible irreversible damage.
- During the replacement of the Battery Module, it is imperative to use the same type and number of elements as the original Battery Module provided with the UPS to maintain an identical level of performance and safety.
- This is a category C3 UPS product. In a residential environment, this product may cause radio interference, in which case the user may be required to take additional measures.

CONTENTS

1	Introduction.....	1
1.1	Product features	1
1.2	Environmental protection	2
2	Product Overview	3
2.1	Model list	3
2.2	Presentation	6
3	Installation	12
3.1	Unpacking and inspecting	12
3.2	Checking the accessory kit	13
3.3	Mechanical installation	14
3.4	Power cables connection	18
4.	Parallel System Installation and Operation (Optional)	33
4.1	Wiring for AC/DC cable	33
4.2	Wiring for parallel signal cable.....	38
4.3	Parallel system operation.....	39
5	Operation	40
5.1	LCD panel	40
5.2	LCD description	41
5.3	Menu structure	42
5.4	Control and Product information.....	43
5.5	User settings	43
5.6	Starting the UPS with utility.....	44
5.7	Starting the UPS on battery	46
5.8	UPS shutdown.....	46
6	Communication	47
6.1	RS232 and USB.....	47
6.2	UPS remote control functions.....	47
6.3	IoT.....	48
6.4	Modbus TCP.....	49
6.5	Intelligent card (optional)	49
6.6	UPS management software	49
7	UPS Maintenance	51
7.1	Equipment care.....	51
7.2	Transporting the UPS	51
7.3	Storing the equipment.....	51
7.4	Recycle.....	51
8	Troubleshooting.....	52
8.1	Typical alarms and faults.....	52
9	Specifications.....	55
9.1	UPS block diagram	55
9.2	UPS specification	55

1 Introduction

Thank you for selecting our UPS to protect your electrical equipment.

We recommend that you take the time to read this manual to take full advantage of the many features of your UPS.

Before installing your UPS, please read the booklet presenting the safety instructions. Then follow the indications in this manual.

1.1 Product features

The UPS protects your sensitive electronic equipment from the most common power problems, including power failures, power sags, power surges, brownouts, line noise, high voltage spikes, frequency variations, switching transients, and harmonic distortion.

Special characteristic:

- Double converter with pure sine waveform output
- Full digital control
- Output PF = 1
- High charger capability, the charger current is up to 13Amps
- Smart charging method to expand battery life time
- EBM quantity auto detection
- Communication ports: RPO, Dry in, Dry out, intelligent slot, USB, RS232
- IoT: Ethernet(default) and Wireless (optional)
- Dot-matrix touch LCM, it supports multi-language
- 3 mode compatible (3-3 mode/ 3-1 mode/ 1-1 mode, default is 3-3 mode)
- ECO Mode
- Start-able without battery

1.2 Environmental protection

Products are developed according to an eco-design approach.

Substances

This product does not contain CFCs, HCFCs or asbestos.

Packing

To improve waste treatment and facilitate recycling, separate the various packing components.

- The cardboard we use comprises over 50% of recycled cardboard.
- Sacks and bags are made of polyethylene.
- Packing materials are recyclable.

Follow all local regulations for the disposal of packing materials.

Product

The product is mainly made up of recyclable materials.

Dismantling and disassembly must take place in compliance with all local regulations concerning waste. At the end of its service life, the product must be transported to recycling centers, re-use and treatment facilities for waste electrical and electronic equipment (WEEE).

Battery

The product contains lead-acid batteries that must be processed according to applicable local regulations concerning batteries.

The battery may be removed to comply with regulations and in view of correct disposal.

2 Product Overview

2.1 Model list



1. 'xxK' model means 'standard model' with batteries, 'xxKS' model means 'long backup time model' without battery.
2. UPS 10kVA and EBM (for 10kVA) is 2*8 or 2*10 batteries selectable, UPS 15/20kVA and EBM (for 15/20kVA) is 2*16 or 2*20 batteries selectable.
3. The weight in this table is reference only, please see the labels on the carton for details.
4. Dimension 'D' is chassis only, not including panel.

● Tower model:

Product	Description	Net Weights (kg)	Unit Size (W x H x D)(mm)
UPS	Tower 3-3 10K 16 TFT	96	300*805.5*633.2
	Tower 3-3 10K 20 TFT	106	
	Tower 3-3 15K 32 TFT	129.4	
	Tower 3-3 15K 40 TFT	146.7	
	Tower 3-3 20K 32 TFT	139	
	Tower 3-3 20K 40 TFT	159.5	
	Tower 3-3 10KS 16 TFT	52.9	
	Tower 3-3 10KS 20 TFT		
	Tower 3-3 15KS 32 TFT	54.2	
	Tower 3-3 15KS 40 TFT		
	Tower 3-3 20KS 32 TFT		
	Tower 3-3 20KS 40 TFT		
EBM	Tower EBM (2) ±96 9AH ⁽¹⁾	95.2	225*589*416
	Tower EBM (2) ±120 9AH ⁽¹⁾	115.6	
	Tower EBM ±192 9AH ⁽²⁾	95.2	
	Tower EBM ±240 9AH ⁽²⁾	115.6	

(1) For tower 10kVA UPS.

(2) For tower 15/20kVA UPS.

● RT model:

Product	Description	Net Weights (kg)	Size (W x H x D)(mm)
UPS	RT 3-3 10KS 16 TFT	23.8	438*129(3U)*559
	RT 3-3 10KS 20 TFT		
	RT 3-3 15KS 32 TFT	24.8	
	RT 3-3 15KS 40 TFT		
	RT 3-3 20KS 32 TFT		
	RT 3-3 20KS 40 TFT		
	RT 3-3 10K 16 TFT	23.8	
	RT 3-3 10K 20 TFT		
	RT 3-3 15K 32 TFT	24.8	
	RT 3-3 15K 40 TFT		
	RT 3-3 20K 32 TFT		
	RT 3-3 20K 40 TFT		
EBM	RT EBM ±96 9AH ⁽¹⁾	52.3	438*129(3U)*559
	RT EBM ±120 9AH ⁽¹⁾	61	
	RT EBM 192 7AH ⁽²⁾	46.1	
	RT EBM 240 7AH ⁽²⁾	56.1	
	RT EBM 192 9AH ⁽³⁾	51.8	
	RT EBM 240 9AH ⁽³⁾	60.5	

(1) For RT 10kVA UPS.

(2) For RT 15kVA UPS. Each RT 15kVA UPS needs 2pcs RT EBM for positive and negative battery input.

(3) For RT 20kVA UPS. Each RT 20kVA UPS needs 2pcs RT EBM for positive and negative battery input.

- Optional modular or accessory:

If order other type function modular or accessories, please contact distributors/agents.

Type	Description	Remark
RT MBP	RT 3-3 10K/15K/20K MBP	For RT model only
	RT 3-3 10K/15K/20K PARA MBP	For RT model only in a parallel system installation
Intelligent Card	Dry Contact card (AS400)	See in chapter 6.5
	NMC card	
	MODBUS card (CMC)	
EMP	Temperature and humidity sensors	
WLAN module	WLAN module	Wireless connection for IoT
COMM Cable	RS232 CABLE	For RS232 communication
Battery cable	Battery cable (16 or 32 batteries) for Tower UPS connect with user's own EBM	1.8m length, see in chapter 3.4.3
	Battery cable (20 or 40 batteries) for Tower UPS connect with user's own EBM	
Rail kit	Rail kit for RT model in Rack installation	See in chapter 3.3.2


2.2 Presentation

2.2.1 Tower model:

- UPS modular:


Front view

1. Ventilation area
2. LCD Modular, including:
 - (1)---Power button
 - (2)---Touch screen
 - (3)---LED indicator



Rear view


1. Intelligent slot
2. RS232
3. Ethernet port (RJ45, for IoT function)
4. USB
5. Wireless (HDMI, For IoT function)
6. Parallel port (optional by factory, default is no)
7. DRY in/out
8. RPO
9. RJ45 (for EBM detect)
10. Maintenance bypass switch
11. Main input switch and bypass input switch
12. AC Input /Output port (terminal block)
13. External battery port



- EBM (External Battery Modular):


Front view

1. Ventilation area
2. EBM label



Rear view

1. Fuse board cover (replace EBM fuse)
2. EBM port 1
3. EBM port 2
4. EBM detection (RJ45 port)




2.2.2 RT model:

- UPS Modular

Front view

1. Ventilation area

2. LCD Modular, including: (1)---Power button (2)---Touch screen (3)---LED indicator



Rear view

1. Intelligent slot

2. RS232

3. Ethernet port (RJ45, for IoT function)

4. USB

5. Wireless (HDMI, For IoT function)

6. Parallel port (optional by factory, default is no)


7. DRY in/out

8. RPO

9. RJ45 (for EBM detection/RT MBP detection)

10. AC input/output port (terminal block)


11. External battery port (terminal block)



- EBM (External Battery Modular):


Front view

1. EBM label area
2. EBM label




Rear view of EBM (for 10kVA)

1. Fuse board cover (replace EBM fuse)
2. EBM port 1
3. EBM port 2
4. EBM detection Box (RJ45 port)
5. Ground screw



Rear view of EBM (for 15/20kVA)

1. Fuse board cover (replace EBM fuse)
2. EBM port 1
3. EBM port 2
4. EBM detection Box (RJ45 port)
5. Ground screw



3 Installation

It is recommended to move the equipment to the installation site by using a pallet jack or a truck before unpacking.

The system may be installed only by qualified electricians in accordance with applicable safety regulations.

The cabinet is heavy, please install it with at least two peoples.


3.1 Unpacking and inspecting




Unpacking the unit in a low-temperature environment may cause condensation occurred in and on the cabinet. Do not install the unit until the inside and outside of the unit are absolutely dry (hazard of electric shock).

If any equipment has been damaged during shipment, keep the shipping cartons and packing materials for the carrier or place of purchase and file a claim for shipping damage. If you discover damage after acceptance, file a claim for concealed damage.


Tower UPS




Tower EBM



RT UPS



RT EBM

Note:

The cabinet is heavy, please see weight provided on the carton/label.

Do not lift the unit's front panel and rear panel.

Discard or recycle the packaging in a responsible manner, or store it for future use.



Packing materials must be disposed in compliance with all local regulations concerning waste.

3.2 Checking the accessory kit

Verify that the following additional items are included with the unit.

Maxima Tower model:

	Long backup time model	Standard model	Tower EBM
	10KS/15KS/20KS	10K/15K/20K	
Battery cable	○		✓
EBM detection cable			✓
Copper bus-bar	✓	✓	
USB cable	✓	✓	
RS232 cable	○	○	
Parallel cable	○	○	
Tower foot	✓	✓	✓
Quick start (EBM)			✓
User manual (UPS)	✓	✓	

RT model:

	Long backup time model	Standard model	RT EBM
	10KS/15KS/20KS	10K/15K/20K	
Battery cable (EBM to UPS)		✓	
Battery cable (EBM to EBM)		✓	✓
EBM detection cable			✓
Copper bus-bar (with jumper cable)	✓	✓	

USB cable	√	√	
RS232 cable	○	○	
Parallel cable	○	○	
Tower foot	√	√	
Rack ear	√	√	√
Rack rail kit	○	○	○
Quick start (EBM)			√
User manual (UPS)	√	√	

Note: √--- Standard configuration; ○---Option, default is Not configured


3.3 Mechanical installation

3.3.1 Tower model

To keep air-flowing freely, it is recommended to keep a clearance with 500mm space both for front and rear side.

UPS model

- 1.Place the unit on a flat surface in its final location and install 'Tower foot' for stability.
- 2.Install the unit to ground(optional): place 4pcs bolts (M8 is recommended) to the final location previously, bolt's position please refer to below, then fix the unit to the bolts.




EBM model



It is recommended to place EBM modular to UPS's right side.

1. Place the unit on a flat surface in its final location and install 'Tower foot' for stability.
2. Install the unit to ground(optional): place 4pcs bolts (M8 is recommended) to the final location previously, bolt's position please refer to below, then fix the unit to the bolts.



3.3.2 RT model:

1. This model support 2 installation modes: Rack installation and Tower installation.
2. To keep good ventilation, please keep a free-space (500mm at least) for front / rear panels of the module.
3. Do not carry the front/rear panel of the module during installation.


● Rack installation

This procedure is suitable for 19 inches rack cabinet installation, it is recommended that the depth of the cabinet be no less than 800mm.


UPS model

Identify the final position and keep '3U' space for this installation.


1. Install the rail kit (if configured). This rail kit is '2U & with screw holes (M5)', the depth of the rail kit is: 443-773 mm.




Fasten the rail kit to the cabinet with 8pcs M5 screws + washers (as below):



2. Install 'Rack ear' to the unit by the M4 screws (flat head).



3. Slide the unit into 'rail kit' and make sure tighten the 'rack mounting screw'.




EBM model

EBM modular installation steps are same as UPS as above, Pay attention to this installation:




1. EBM modular must be installed on the lower level of the UPS (as shown below).
2. 2 EBMs are required for RT 15/20kVA UPS, each EBM with a height of 3U; therefore, 6U installation space is required.



● Tower installation

UPS model

Screw the tower foot to UPS: The LCD of this UPS modular has gravity sensing, the vision window can automatically adjust the display direction (as below).



EBM model



1. Place EBM modular to UPS's right side and align with front-panel.
 2. Screw the UPS's tower foot: one is to UPS's side, another one to EBM's side (as above)
- 2 EBMs are required for RT 15/20kVA UPS, please keep an enough space for installation.


3.4 Power cables connection

This chapter introduces how to wire AC IN/OUT cable to UPS in different mode, and UPS connecting with EBM/MBP.


3.4.1 Input /Output wiring specification

Before wiring UPS, upstream breaker and backfeed contactor should be configured to avoid power backfeed to maxima. And 'backfeed voltage danger' warning label should be added in backfeed contactor or device. Before operating, UPS input should cut off, and check all terminals voltage to avoid voltage dangerous. Backfeed contactor rating current should be larger than UPS rating input current.

Below figures show the wiring system of UPS input.



Single phase input system



Three phase input system

Danger!



The rated current of the utility power switch must be greater than the UPS input current, otherwise the utility power switch may be burnt!

Recommended circuit breaker and contactor current specifications:

UPS power rating	Input mode	Breaker	Contactor
10000VA	1 phase main input	80A	≥80A
	3 phase main input	32A	≥32A
	1 phase bypass input	63A	≥63A
	3 phase bypass input	32A	≥32A
15000VA	1 phase main input	125A	≥125A
	3 phase main input	50A	≥50A
	1 phase bypass input	100A	≥100A
	3 phase bypass input	50A	≥50A
20000VA	1 phase main input	160A	≥160A
	3 phase main input	63A	≥63A
	1 phase bypass input	125A	≥125A
	3 phase bypass input	63A	≥63A

Recommended output circuit breaker current specifications:

UPS power rating	Output mode	Breaker current
10000VA	1 phase output	63A
	3 phase output	32A
15000VA	1 phase output	100A
	3 phase output	50A
20000VA	1 phase output	125A
	3 phase output	63A

Recommended battery circuit breaker current specifications:

UPS power rating	Breaker current
10000VA	80A
15000VA	63A
20000VA	80A



Read the Safety instructions regarding backfeed protection requirements.

Recommended cable minimum cross-sectional area (unit: mm²)

UPS power rating	Input/ Output Mode	Input					Output			Battery	
		Main input		Bypass input		Ground wire	L wire	N wire	Ground wire	+/- wire	Ground wire
		L wire	N wire	L wire	N wire						
10000VA	3-3	4	4	4	4	10	4	4	4	10	10
	3-1	4	4	10	10	10	10	10	10	10	10
	1-1	16	16	10	10	16	10	10	10	10	10
15000VA	3-3	6	6	6	6	10	6	6	6	10	10
	3-1	6	6	16	16	16	16	16	16	10	10
	1-1	35	35	16	16	35	16	16	16	10	10
20000VA	3-3	10	10	10	10	10	10	10	10	10	10
	3-1	10	10	25	25	25	25	25	25	10	10
	1-1	50	50	25	25	50	25	25	25	10	10

Note:

1. Please select the larger cross-section conductor for the UPS input cable in the single source application.
2. UPS output cable length is recommended not to exceed 10m.
3. In the three-phase output mode, if the load is an unbalanced load, the L wire of the bypass and output may exceed the rated current, and the maximum rated current will be 1.732 times. The corresponding protection device and wiring cable must be determined according to the standards of the region and the actual situation of the user.

3.4.2 Wiring for AC cable (AC source to UPS)



High leakage current:

Earth connection essential before connecting supply.




This type of connection must be carried out by qualified electrical personnel.

Before carrying out any connection, check that the upstream protection devices (Normal AC source and Bypass AC source) are open 'O' (Off).

Always connect the ground wire first.

Tower model:

Remove the cover of terminal block, Layout of AC input/output as below:




Note:

1. UPS input: PE/N/N/mL1/bL1/mL2/bL2/mL3/bL3('m' is main input, 'b' is bypass input)
2. UPS output: N/N/L1/L2/L3/PE

UPS provide busbars (as below) for 6 modes of wiring application, default is 3-3 mode (single source).

Busbars		Mode					
Item#	Figure	Single source 3-3	Dual source 3-3	Single source 3-1	Dual source 3-1	Single source 1-1	Dual source 1-1
1		5pcs	2pcs	2pcs	2pcs	2pcs	2pcs
3				1pc	1pc	1pc	1pc
4				1pc			
5					1pc		1pc
6						1pc	
7							1pc

- **Mode 3-3(single source)**



Input: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Short terminal mL1/ bL1 with busbar #1, connect AC cable(L1);

Short terminal mL2/ bL2 with busbar #1, connect AC cable(L2);


Short terminal mL3/ bL3 with busbar #1, connect AC cable(L3).

Output: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Connect terminal L1/L2/L3 to AC cable(L1/L2/L3).

- **Mode 3-3(dual source)**



Input: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC main source cable(N) and bypass source cable(N);

Connect input terminal mL1/mL2/mL3 to main source cable(L1/L2/L3);


Connect bypass terminal bL1/bL2/bL3 to bypass source cable(L1/L2/L3).

Output: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Connect terminal L1/L2/L3 to AC cable(L1/L2/L3).


- **Mode 3-1(single source)**



Input: Connect ground cable (PE) to ground screw of chassis first;
 Short terminal N/N with busbar #1, connect AC cable(N);
 Short input terminal mL1/bL1/bL2/bL3 with busbar #4, connect to AC cable(L1);
 Connect terminal mL2 to AC cable(L2) and terminal mL3 to AC cable(L3).

Output: Connect ground cable (PE) to ground screw of chassis first;
 Short terminal N/N with busbar #1, connect AC cable(N);
 Short terminal L1/L2/L3 with busbar #3, connect AC cable(L).


- **Mode 3-1(dual source)**



Input: Connect ground cable (PE) to ground screw of chassis first;
 Short terminal N/N with busbar #1, connect AC main source cable(N) and bypass source cable(N);
 Connect input terminal mL1/mL2/mL3 to main source cable(L1/L2/L3);
 Short bypass terminal bL1/bL2/bL3 with busbar #5, connect bypass source cable(L).

Output: Connect ground cable (PE) to ground screw of chassis first;
 Short terminal N/N with busbar #1, connect AC cable(N);
 Short terminal L1/L2/L3 with busbar #3, connect AC cable(L).

- Mode 1-1(single source)



Input: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);


Short terminal mL1/bL1/mL2/bL2/mL3/bL3 with busbar #6, connect AC cable(L).

Output: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Short terminal L1/L2/L3 with busbar #3, connect AC cable(L).

- Mode 1-1(dual source)



Input: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC main source cable(N) and bypass source cable(N);

Short input terminal mL1/mL2/mL3 with busbar #7, connect main source cable(L);

Short bypass terminal bL1/bL2/bL3 with busbar #5, connect bypass source cable(L).


Output: Connect ground cable (PE) to ground screw of chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Short terminal L1/L2/L3 with busbar #3, connect AC cable(L).

RT model:

Remove the cover of terminal block, Layout of AC input/output as below:



Note:

1. UPS input(PE/N/N/L1/L2/L3)
2. UPS bypass input(L1/L2/L3)
3. UPS output (PE/N/N/L1/L2/L3)
4. External battery port(PE/+N/N/-)

UPS provide busbars and jumper cables as below for 6 modes of wiring application, default is Mode 3-3(single source).

			Mode					
	Item#	Figure	3-3 Single source	3-3 Dual source	3-1 Single source	3-1 Dual source	1-1 Single source	1-1 Dual source
Copper busbar	1		2pcs	2pcs	2pcs	2pcs	2pc	2pcs
	2				2pcs	2pcs	2pcs	3pcs
Jumper cable			3pc		1pc		3pc	

- Mode 3-3(single source)



Input: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);


Connect input terminal L1/L2/L3 with AC cable(L1/L2/L3) and jumper cable, then fix 'jumper cable' to bypass terminal L1/L2/L3'.

Output: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, then connect AC cable(N);

Connect terminal L1/L2/L3' to AC cable(L1/L2/L3).

- Mode 3-3(dual source)



Input: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC main source cable(N) and bypass source cable(N);


Connect input terminal L1/L2/L3 to main source cable(L1/L2/L3) and bypass terminal L1/L2/L3 to bypass source cable(L1/L2/L3).

Output: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Connect terminal L1/L2/L3' to AC cable(L1/L2/L3).

- Mode 3-1(single source)



Input: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Connect input terminal L2/L3 to AC cable(L2/L3);


Fix 'jumper cable' to input terminal L1 and busbar #2, short bypass terminal L1/L2/L3 with this busbar #2, connect AC cable(L1).

Output: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Short terminal L1/L2/L3 with busbar #2, connect AC cable(L).

- Mode 3-1(dual source)



Input: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC main source cable(N) and bypass source cable(N);

Connect input terminal L1/L2/L3 to main source cable(L1/L2/L3);


Short bypass terminal L1/L2/L3 with busbar #2, connect bypass source cable(L).

Output: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Short terminal L1/L2/L3 with busbar #2, connect AC cable(L).

- Mode 1-1(single source)



Input: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);


Fix 'jumper cable' to input terminal L1/L2/L3 and busbar #2, short bypass terminal L1/L2/L3 with this busbar #2 and connect AC cable(L).

Output: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);

Short terminal L1/L2/L3 with busbar #2, connect AC cable(L).

- Mode 1-1(dual source)



Input: Connect ground cable (PE) to chassis first;

Short terminal N/N with 'busbar #1', connect AC main source cable(N) and bypass source cable(N);

Short input terminal L1/L2/L3 with busbar #2, connect main source cable(L);

Short bypass terminal L1/L2/L3 with busbar #2, connect bypass source cable(L).

Output: Connect ground cable (PE) to chassis first;

Short terminal N/N with busbar #1, connect AC cable(N);


Short terminal L1/L2/L3 with busbar #2, connect AC cable(L).

3.4.3 Wiring with external battery modular (EBM) (DC source to UPS)




1. Be sure to disconnect the battery cable from the EBM before connecting the battery terminals of the UPS.
2. Make sure the UPS is completely off before connecting or disconnecting the EBM.
3. Before connecting the EBM, make sure that the EBM specifications is compatible with UPS configuration.
4. Do not reverse the polarity of the external battery.

EBM wiring schematic diagram is shown below:




Single set of EBM



Multiple sets of EBMs

- Connect with the configured EBM:
Connect EBM to UPS with 'Battery cable' and 'EBM detect cable'.


Tower EBM



Note: EBM automatic detection function supports up to 3 EBMs for Maxima Tower 10kVA UPS. For more EBM quantity (max to 6), need configure the battery capacity in LCD. Extended runtime with up to 6 EBMs for each Tower 15/20kVA UPS.


RT EBM

For 10kVA UPS:



Note: Extended runtime with up to 6 EBMs for each RT 10kVA UPS.

For 15-20kVA UPS:




Note: Extended runtime with up to 6 sets of EBM for each RT 15/20kVA UPS.

- Connect with user's own EBM:



Tower model:

Connect user's own EBM to UPS with 'Battery cable'(if configured).



RT model:

Connect user's own EBM to UPS with below indication of 'External battery port':




Note:

1. The EBM must be grounded individually or grounded to UPS.
2. If additional battery cable needed for installation, it must follow cable specification and the maximum length of battery cable 10 meters for application; If a length of battery cable over 10 meters requests, please contact distributors/agents for details.
3. DC breaker or DC fuse is required for each EBM.

3.4.4 Wiring with RT MBP (MBP source to RT UPS only)

RT MBP is RT UPS's optional modular, UPS can be used with the MBP to implement the maintenance bypass switching function to ensure that the output of the system is not affected during the UPS maintenance.

See the User Manual of RT MBP for details.




4. Parallel System Installation and Operation (Optional)

If your UPS is configured with parallel function, up to 3 UPSs can be connected in parallel to configure a sharing and redundant output power.

In parallel system, the mechanical installation for each modular is same as the single system. Details please refer to Chapter 3.3.

Parallel system AC cable diagram:



4.1 Wiring for AC/DC cable

1. Wiring length requirement:



When the distance between the load and the parallel UPS is less than 10 meters, the length difference between the input/output lines between the UPSs in the parallel system is less than 20%.

When the distance between the load and the parallel UPS is greater than 20 meters, the length difference between the input/output lines between the UPSs in the parallel system is less than 5%.

- Professional installation is required, please set the parallel system in the restricted area!
This chapter introduces how to wire AC IN/OUT cable to UPS in parallel system, and UPS connecting with EBM/MBP.

4.1.1 Input /Output wiring specifications

Cable-select table for the parallel system AC IN, AC OUT and Battery wire:

Parallel system installed by 10kVA UPS (conductor cross-section, unit: mm ²)											
UPS number	Mode	Main input		Bypass input		Ground wire	Output			Battery wire	Battery ground
		L wire	N wire	L wire	N wire		L wire	N wire	Ground		
2 UPS	3-3	10	10	6	6	10	6	6	6	35	35
	3-1	10	10	25	25	25	25	25	25	35	35
	1-1	50	50	25	25	50	25	25	25	35	35
3 UPS	3-3	16	16	10	10	16	10	10	10	70	70
	3-1	16	16	50	50	50	50	50	50	70	70
	1-1	95	95	50	50	95	50	50	50	70	70

Parallel system installed by 15kVA UPS (conductor cross-section, unit: mm ²)											
UPS number	Mode	Main input		Bypass input		Ground wire	Output			Battery wire	Battery ground
		L wire	N wire	L wire	N wire		L wire	N wire	Ground		
2 UPS	3-3	16	16	10	10	16	10	10	10	25	25
	3-1	16	16	50	50	50	50	50	50	25	25
	1-1	95	95	50	50	95	50	50	50	25	25
3 UPS	3-3	35	35	16	16	35	16	16	16	50	50
	3-1	35	35	95	95	95	95	95	95	50	50
	1-1	185	185	95	95	185	95	95	95	50	50

Parallel system installed by 20kVA UPS (conductor cross-section, unit: mm ²)											
UPS number	Mode	Main input		Bypass input		Ground wire	Output			Battery wire	Battery Ground
		L wire	N wire	L wire	N wire		L wire	N wire	Ground		
2 UPS	3-3	25	25	16	16	25	16	16	16	35	35
	3-1	25	25	70	70	70	70	70	70	35	35
	1-1	120	120	70	70	120	70	70	70	35	35
3 UPS	3-3	50	50	25	25	50	25	25	25	70	70
	3-1	50	50	150	150	150	150	150	150	70	70
	1-1	240	240	150	150	240	150	150	150	70	70


Note:

1. Please select the larger cross-section conductor for the parallel system 'AC IN cable' in the single source application.
2. In the three-phase output mode, if the load is an unbalanced load, the L wire of the bypass and output may exceed the rated current, and the maximum rated current will be 1.732 times. The corresponding protection device and wiring cable must be determined according to the standards of the region and the actual situation of the user.


4.1.2 Wiring for AC cable (AC source to UPS)

AC cable wiring are shown in below diagrams for different configuration.


- 3-3 configuration (single source)




- 3-3 configuration (dual source)




- 3-1 configuration (single source)




- 3-1 configuration (dual source)



- 1-1 configuration (single source)



- 1-1 configuration (dual source)




4.1.3 Wiring with external battery modular (EBM) (DC source to UPS)

- **Parallel UPS connection with ‘independent battery’**

In the parallel system, independent EBM connect to each UPS please refer to chapter 3.4.3.

- **Parallel UPS connection with ‘common battery’**


In the parallel system, you can also set up ‘common battery’(user’s own battery) for all UPSs. Please refer to below diagram for battery wiring.




Note: Common battery configuration is not suitable for standard model.

4.2 Wiring for parallel signal cable

Parallel system ‘parallel cable’ diagram:



Connect each UPS one by one with 'parallel cable', make sure the cable is screwed to parallel port tightly.



It is recommended to lock the 'parallel cable' (as above) for preventing the parallel ports suffering an unexpected pulling-force and causing the parallel system fault.

4.3 Parallel system operation

1. Turn on the input breakers for the parallel UPS.
2. Pressing  button continuously for one UPS of the system, then the system will start to turn on and enter line mode.
3. Regulate the output voltage of each UPS separately, and check if the output voltage difference is less than 0.5V among the parallel system. If the difference is more than 0.5V, the UPS need to be regulated.
4. If the output voltage difference is less than 0.5V, pressing  button continuously for one UPS of the system to turn off the system. Turn off the input breakers to let UPS shut down.
5. Connect 10% load at least and then turn on the output breakers for all the UPS.
6. Turn on the input breakers for the parallel UPS. Pressing  button continuously for one UPS of the system, then the system will start to turn on and enter line mode and the system will work normally in parallel.

5 Operation

5.1 LCD panel

The UPS has a touch graphical LCD. It provides useful information about the UPS itself, load status, events, measurements and settings.



The LED:

LED status	description	UPS status
	Red on	Fault mode
	Red flash	General alarm
	Yellow on	Battery mode
	Yellow flash	Bypass mode with output
	Green on	Line mode or HE mode
	off	No output (power on/shutdown/bypass without output)


The button:

button	function	description
	On/off	When only battery power is available, press to power on When UPS is not turned on, pressing this key to turn on When working normally, press to pop up the shutdown page When the UPS is in fault mode, press to clear the fault (some faults cannot be cleared directly)


The Buzzer:

The buzzer	General Meaning
1 beep every 2 minutes	Load supplied on bypass
1 beep every 4 seconds	Load supplied on battery If battery low, beep every second
1 beep every second	General warning active
2 beeps every second	Overload warning
Continuous	Fault active
Only beep	Touch screen operation sound


5.2 LCD description



Display Area	Icon	Description
Battery status	 100%  126min	Battery capacity Backup time
UPS mode	Line Mode	The work mode of the UPS
Load percentage	 50% 50% L1  50% L2 50% L3	When it is 3 phase output, the load for each of the 3 phases is displayed in this area
Bypass status and measurements	 Bypass  Bypass	Different icon shows the phase number of bypass Click on this icon will bring up a popup of measurements of the bypass
Battery status and measurements	 Battery	Click on this icon will bring up a popup of measurements of the battery
Line status and measurements	 Line  Line	Different icon shows the phase number of Utility Click on this icon will bring up a popup of measurements of the utility
Output status and measurements	 Output  Output	Different icon shows the phase number of output Click on this icon will bring up a popup of measurements of the output

Energy flow chart		The thick solid line means there is energy flow, the double thin line means nothing
System time		It can be set in user settings
Menu icon		Click on this icon can entry the menu screen
Alarm area		When UPS enters fault mode, fault ICON and the fault information will be displayed. If alarms exist, alarm information will scroll for up to 4 messages, each for 2 seconds
Para ID		The UPS ID number in parallel system (1-3), keep 1 in single mode

5.3 Menu structure



5.4 Control and product information

Main menu	Submenu	Menu function
Control	Battery test	Starts a manual battery test in stand-alone mode
	Reset IoT function	Reset IoT function inside UPS
	Battery test (Parallel)	Starts a single battery test in parallel mode
	Reset fault	Clear active fault
	Reset factory setting	Restore to default factory settings
	Single UPS shutdown	Operate this machine to exit parallel connection
Product Info	UPS model	Model name & input/output phase
	Serial number	Serial number of UPS
	UPS firmware version	Version of UPS firmware
	LCD firmware	Version of UI
	JHD-APP version	Version of LCD driver
	Communication card firmware version	Version of IoT
	Ethernet IP	IP address of ethernet
	Ethernet MAC	MAC address of ethernet
	WLAN IP	IP address of WLAN
WLAN MAC	MAC address of WLAN	

5.5 User settings

Setting	Options on the display	Default	
General	Audible Alarm	[Enabled], [Disabled]	Enabled
	Date/Time	YYYY-MM-DD HH:MM	2020-1-1
	Language	English, Italiano, Français, Deutsch, Español, Русский, Polski, 简体中文	English
	LCD brightness	[0%~100%]	100%
	LCD saving mode	[Enabled], [Disabled]	Enabled
	Screen rotation	[Auto Rotate], [Horizontal], [Vertical]	Auto Rotate
Input	Site wiring fault ⁽¹⁾	[Enabled], [Disabled]	Disabled
	Bypass voltage low limit	110 ~ (V_inverter - 15V)	187V
	Bypass voltage high limit	(V_inverter + 15V) ~ 276V	264V
	Bypass frequency low limit	-10%~-5%	-10%
	Bypass frequency high limit	5%~10%	10%
	HE voltage low limit	-15%~-5%	10%
	HE voltage high limit	5%~20%	10%
	HE frequency low limit	-10%~-5%	5%
	HE frequency high limit	5%~10%	5%
	Dual input function	[Enabled], [Disabled]	Disabled

Output	UPS Mode	[Normal mode], [HE mode], [CVCF mode]	Normal mode
	Output voltage	[220V], [230V], [240V]	230V
	Output frequency	[Auto detection], [50Hz], [60Hz]	Auto detection
	ESS function	[Enabled], [Disabled]	Disabled
	Auto bypass	[Enabled], [Disabled]	Enabled
	Auto restart	[Enabled], [Disabled]	Enabled
	Short circuit auto clear	[Enabled], [Disabled]	Disabled
	Overload pre-alarm	50%~105%	105%
Battery	DC Start	[Enabled], [Disabled]	Enabled
	Battery Auto Test	[Every cycle] [Disabled]	Every cycle
	Deep discharge protection	[Enabled], [Disabled]	Enabled
	Low bat warning	0%~100%	0%
	Low remaining time warning	0-999min	0min
	Restart battery level	0~100%	0%
	Charger current	[1-13A]	[4A] for 10-20KS [1.4A] for 15K [2A] for 10K/20K
External battery setting	[Auto detection], [Manual AH setting] Manual AH setting: [9-300AH]	[Auto detection] /	
Communication	Dry in	[No function] [Start UPS] [Remote shut down] [Maintenance bypass]	No function
	Dry out	[load powered] [on battery] [Low battery] [No Battery] [Bypass] [ups OK]	load powered
	IoT function	[Enabled], [Disabled]	Disabled
	Modbus TCP	[Enabled], [Disabled]	Disabled
Password	Control Menu password	[Enabled], [Disabled]	Enabled
	Setting Menu password	[Enabled], [Disabled]	Enabled
	Change Password	Old password New password Confirm password	[4732]

- (1) Site wiring fault function is only for single phase bypass input. If the utility power is IT system, the site wiring fault function should be disabled.

5.6 Starting the UPS with utility

Startup preparation:




Before starting up the UPS, please make sure that the wiring is securely connected, otherwise there is a danger of electric shock.

- Verify that the total UPS output load does not exceed the rated capacity of the UPS.
- The wiring of the UPS input and output is correctly connected according to the required mode.
- Confirm that the UPS output device is not started.
- Make sure the UPS is reliably connected to the battery.
- Connect communication interfaces that need to be used.

Startup the UPS with utility power:

1. Turn on input breaker and output breaker.
2. The fan starts to rotate, the LCD displays startup animation, then enters the main page.
3. UPS default Bypass enable, the main page shows UPS working in bypass mode.
4. The default input/output mode is three-input and three-out. If it is inconsistent with the actual wiring, it needs to be changed to the actual wiring mode.
5. Press the button for more than 1 second, the buzzer will beep and the UPS will start up. After a few seconds, the UPS will go to normal mode.



6. If the utility power is abnormal, the UPS will transfer to Battery mode.
7. When the battery is not connected, the UPS can still be startup. After the startup, there is alarm of battery not connected. If the utility power is abnormal, the UPS load will not be protected.
8. The load is powered by the UPS and the LCD shows a charging sign indicating that the battery is charging.
9. Startup the output device.



If you want to cancel the Bypass enable function, please refer to chapter “User setting”.

The input/output mode is modified by the service personnel:

1. Pull out the RPO connector.
2. Turn on input breaker, check the UPS mode in the LCD. If it is different from the actual wiring mode, change to the actual wiring mode.
3. Power off the UPS completely. Then power on, confirm that the mode is set correctly.
4. Power off the UPS again, insert the RPO terminal.

5.7 Starting the UPS on battery



Before using this feature, the UPS must have been powered by utility power with output enabled at least once.

Battery start can be disabled. See the "DC start" setting in "Battery/DC Start".

To start the UPS on battery:

1. Press the button for more than 0.1 seconds. The UPS establishes the power, the fan starts to rotate, the LCD displays the startup animation, and then enters the main page to display the standby mode.
2. If there is no operation, the LCD is off out after 10 seconds and the UPS is powered down.
3. Press the button for more than 1 second, the buzzer will beep and the UPS will startup. The UPS will go to battery mode after a few seconds.
4. If the utility power is connected at this time, the UPS will switch to the line mode and the output will be uninterrupted.
5. UPS works in battery mode, and the buzzer beep for 4 seconds to remind that the battery is discharged.
6. Since there is no utility power input, the input abnormal alarm will be displayed on the LCD.

5.8 UPS shutdown

Shutdown the UPS with utility power mode:

1. UPS working with utility power, press the button for more than 3s, the LCD pops up to confirm the shutdown page.
2. After clicking Confirm, the UPS performs shutdown.
3. After shutdown, the UPS works in bypass mode and the output remains powered.
4. If there is no need the UPS output, disconnect the input utility power.

Shutdown the UPS with battery mode:

1. Press the button for more than 3s, the LCD pops up to confirm the shutdown page;
2. After clicking Confirm, the UPS performs shutdown.
3. The UPS output is interrupted and goes into standby mode. After a few seconds, the UPS automatically shuts down.

6 Communication

6.1 RS232 and USB

1. Communication cable to the serial or USB port on the computer.
2. Connect the other end of the communication cable to the RS232 or USB communication port on the UPS.

6.2 UPS remote control functions


- **Remote Power Off (RPO)**

When RPO is activated, UPS will cut off output immediately, and continues to alarm.

RPO	Comments
Connector type	16 AWG Maximum wires
External breaker specification	60 V DC/30 V AC 20 mA max

Reset:


1. Check the RPO connector status;
2. Clear fault state through LCD.



- **Dry in**

Dry in function can be configured. (see Settings > Dry in)


Dry in	Comments
Connector type	16 AWG Maximum wires
External breaker specification	60 V DC/30 V AC 20 mA max



- **Dry out**

Dry out is the relay out, dry out function can be configured. (see Settings > Dry out)

Dry out	Comments
Connector type	16 AWG Maximum wires
Inner Relay specification	24Vdc/1A



6.3 IoT

Built-in ethernet port and WLAN (optional accessory) port enable market-leading and easy-to-use IoT solutions for:

- Winpower View mobile app which allows you to remote monitor UPS(s) and keep informed about critical UPS event always.
- Remote report UPS faults and status (contact with your service for detail) from APP or registered APP account (Email address).
- Automatic UPS and battery warranty alert from APP or registered APP account (Email address).

IoT Connection

- **Wired network connection**

1. Connect UPS to router or switch with network cable
 - Please use CAT6 shielded network cable.
 - Make sure your IT settings can access the public network and Microsoft Azure Cloud.
2. Enable the IoT function in LCD (see Settings -> IoT).
3. Search the “WinPower View” from Google Play store or Apple APP store, downloading and installing.
4. Open the app, register an account, log in, follow the instructions of the app.
5. Tap  on the upper right corner, scan the SN barcode on UPS label to add device.





For more detail information and Q&A about the IoT and APP, please refer to the HELP menu in the app.

- **Wireless network connection**

The wireless module (WLAN dongle) is optional, please contact your local distributor for details.

6.4 Modbus TCP

Built-in ethernet port offers Modbus TCP feature to facilitate remote monitoring of the UPS into your own software. Contact with your service for protocol details.

6.5 Intelligent card (optional)


Intelligent Card allow the UPS to communicate with different types of devices in variety of networking environments. The UPS could use the following connectivity cards, please contact your local distributor for details.

- **NMC Card** - Ideal monitoring solution enables user to monitor and control the status of UPS on web browser via internet.
- **CMC card** - provides connection to Modbus protocol with standard RS485 signal.
- **AS400 G2 card** - Provides voltage-free dry-contact signals for programmable controller and management system.

6.6 UPS management software

6.6.1 WinPower

WinPower provides user-friendly interface to monitor and control your UPS. This unique software provides safely auto shutdown for multi-computer systems while power failure. With this software, users can monitor and control any UPS on the same LAN no matter how far from the UPSs.



Installation procedure:

1. Go to the website: <http://www.ups-software-download.com/content/ups-download-software/download.html>
2. Choose the operation system you need and follow the instruction described on the website to download the software.
3. When downloading all required files from the internet, enter the serial No: **511C1-01220-0100-478DF2A** to install the software.

When you finish installation, restart your computer, the WinPower software will appear as a green plug icon located in the system tray, near the clock.

6.6.2 WinPower View APP

WinPower View is a mobile app which allows you to centralized monitoring UPS(s) connected to cloud. Please download it from Google Play store or Apple APP store. Please refer to the chapter 6.3 for IoT connection.

7 UPS Maintenance

7.1 Equipment care

For the best preventive maintenance, keep the area around the equipment clean and dust free. If the atmosphere is very dusty, clean the outside of the system with a vacuum cleaner.

For full battery life, keep the equipment at an ambient temperature of 25°C (77°F).



The batteries are rated for a 3-5 years service life. The length of service life varies, depending on the frequency of usage and ambient temperature. Batteries used beyond expected service life will often have severely reduced runtimes. Replace batteries at least every 4 years to keep units running at peak efficiency.

7.2 Transporting the UPS



Please transport the UPS only in the original packaging. If the UPS requires any type of transportation, verify that the UPS is disconnected and turned off.

7.3 Storing the equipment

If you store the equipment for a long period, recharge the battery every 6 months by connecting the UPS to utility power. Recommends that the batteries charge for 48 hours after long-term storage.

If batteries were never recharged over 6 months, do not use them. Contact your service representative.

7.4 Recycle

Contact your local recycling or hazardous waste center for information on proper disposal of the used equipment.



Do not dispose of the batteries in the fire. Which may cause battery explosion. The batteries must be rightly disposed according to local regulation.

Do not open or destroy the batteries. Escaping electrolyte can cause injury to the skin and eyes. It may be toxic.

Do not discard the UPS or the UPS batteries in the trash.



This product contains sealed lead acid batteries and must be disposed as it's explained in this manual. For more information, contact your local recycling/reuse or hazardous waste center.



The crossed-out wheeled bin symbol indicates that waste electrical and electronic equipment should not be discarded together with unseparated household waste but must be collected separately. The product should be handed in for recycling in accordance with the local environmental regulations for waste disposal.

By separating waste electrical and electronic equipment, you will help reduce the volume of waste sent for incineration or land-fills and minimize any potential negative impact on human health and environment.

8 Troubleshooting


The UPS is designed for durable, automatic operation and also alert you whenever potential operating problems may occur. Usually the alarms shown by the control panel do not mean that the output power is affected. Instead, they are preventive alarms intended to alert the user.

- Events are silent status information that are recorded into the Event log. Example = "Battery charging".
- Alarms are recorded into the Event log and displayed on the LCD status screen with the logo blinking. Some alarms may be announced by a beep every 1 second. Example = "Battery low".
- Faults are announced by a continuous beep and red LED, recorded into the Event log. Example = Output short circuit.

Use the following troubleshooting chart to determine the UPS alarm condition.


8.1 Typical alarms and faults

To check the fault log or event log:



Click on "Menu" icon


Click on "History" icon



No.	ID#	List	Date
1	000	Output Short Circuit	2019-12-01 12:12:12
2	000	Output Short Circuit	2019-12-01 12:12:12
3	000	Output Short Circuit	2019-12-01 12:12:12
4	000	Output Short Circuit	2019-12-01 12:12:12
5	000	Output Short Circuit	2019-12-01 12:12:12

Click on "Fault" icon



Last 5 faults, blank list if no fault



Click on “Event” icon



Last 100 events




If alarm exists, shows here. 4 messages for high priority alarm

Problem Displayed	Possible cause	Remedy
Site wiring fault	Phase and neutral conductor at input of UPS system are reversed	Reverse mains power wiring
Neutral wire missed	Neutral abnormal	Confirm the connection of the input wires
Pos Bat open	Battery pack is not connected correctly	Do the battery test to confirm; Check the battery bank is properly connected to the UPS; Check the battery breaker is turn on or fuse OK
Neg Bat open	Battery pack is not connected correctly	Do the battery test to confirm; Check the battery bank is properly connected to the UPS; Check the battery breaker is turn on or fuse OK.
Pos Bat Low	Battery voltage is low	When audible alarm sounding every second, battery is almost empty
Neg Bat Low	Battery voltage is low	When audible alarm sounding every second, battery is almost empty.
Pos Over Charge	Battery voltage is high	Consult dealer
Neg Over Charge	Battery voltage is high	Consult dealer
Pos Charger Failure	UPS internal fault	Consult dealer
Neg Charger Failure	UPS internal fault	Consult dealer
Bad Battery Count	Unreasonable battery number	Check whether the actual battery cell number is consistent with the set value


Pos Bus Over Volt	UPS internal fault, the + DC BUS voltage is too high	Consult dealer
Neg Bus Over Volt	UPS internal fault, the -DC BUS voltage is too high	Consult dealer
Pos Bus Under Volt	UPS internal fault, the + DC BUS voltage is too low	Consult dealer
Neg Bus Under Volt	UPS internal fault, the -DC BUS voltage is too low	Consult dealer
Bus Unbalance	UPS internal fault, the voltage difference between DC Bus+ and DC bus- is too large	Consult dealer
Bus Short	UPS internal fault	Consult dealer
Bus Soft Start Fail	UPS internal fault	Consult dealer
Output Short circuit	abnormally low impedance placed on its output and considers it a short circuit	Remove all the loads. Turn off the UPS; Check if UPS output and loads is short circuit; Ensure short circuit is removed before turning on again
L1 Output Short circuit		
L2 Output Short circuit		
L3 Output Short circuit		
Inverter Over Volt	UPS internal fault, the inverter voltage is too high	Consult dealer
Inverter Under Volt	UPS internal fault, the inverter voltage is too low	Consult dealer
Inverter Soft start Fail	UPS internal fault	Consult dealer.
Inverter Overload Fault	Overload	Check the loads and remove some noncritical loads; Check if some loads are failed
Output Overload Fault		
Byp Overload Fault		
Inverter Capacity Open	UPS internal fault	Consult dealer
Primary SPS Fail	UPS internal fault	Consult dealer
Assist SPS Fail		
Emergency Off	Perform emergency shutdown	Check the status of RPO terminal
Internal Over Temp Fault	Inside temperature of UPS is too high	Check the ventilation of UPS and the ambient temperature
Byp SCR Over Temp		
Charger Over Temp Fault		
UPS Ambient Over Temp	The ambient temperature is too high	Check the environment ventilation
Fan Lock	Fan abnormal	Check if the fan is running normally or fan detection cable disconnected
ESS Fan lock		
Model Setting Wrong	Wrong work mode	Consult dealer
Neg Power Fault	Negative power fault	Consult dealer
Para. Cable Lost	The cable is not connected	Please confirm the connection status of the parallel cable
Para. Incompatible	Para setting different	Please check the parallel settings, if it still alarms, please consult dealer.
IoT disconnected	IoT is disabled	Enable IoT function in LCD
	Others	Please refer to Winpower View app help file

9 Specifications

9.1 UPS block diagram



9.2 UPS specification

Models	10K	10KS	15K	15KS	20K	20KS	
Rated power ⁽¹⁾	10kVA/ 10kW	10kVA/ 10kW	15kVA/ 15kW	15kVA/ 15kW	20kVA/ 20kW	20kVA/ 20kW	
Rated frequency	50/60Hz						
Input	Voltage range (Phase voltage)	 <p style="text-align: center;">100~300VAC</p>					
	Rated voltage (Phase voltage)	220/230/240VAC					
	Main input Rated current ⁽²⁾ (3 Phase)	22A	22A	35A	35A	43A	43A
	Main input Rated current ⁽²⁾ (1 Phase)	65A	65A	105A	105A	129A	129A
	Bypass input Rated current (3 Phase)	16A	16A	24A	24A	31A	31A

Models		10K	10KS	15K	15KS	20K	20KS
Input	Bypass input Rated current (1 Phase)	47A	47A	70A	70A	93A	93A
	Main input frequency for 3-3 and 3-1 mode	40-70Hz					
	Main input frequency for 1-1 mode	≤ 60% rated load: 40-70Hz					
		> 60% rated load ⁽¹⁾ : 45-55Hz(50Hz system) / 54-66Hz(60Hz system)					
Bypass Input frequency		45-55Hz(50Hz system) / 54-66Hz(60Hz system)					
Charging current ⁽¹⁾		1~13A adjustable					
Charging current (default)		2A	4A	1.4A	4A	2A	4A
Output	Rated voltage (Phase voltage)	220/230/240VAC					
	Overload	105%-125% Load, 10 minutes transfer to Bypass; 125%-150% Load, 30 seconds transfer to Bypass; >150% Load, 0.5 seconds transfer to Bypass					
	Short-circuit current on normal mode (3 Phase output)	30A for 10±1 cycle		56.8A for 10±1 cycle		74A for 10±1 cycle	
	Short-circuit current on normal mode (1 Phase output)	90A for 10±1 cycle		171A for 10±1 cycle		222A for 10±1 cycle	
Transfer Time Line<->Battery		0ms					
Transfer Time INV<->Bypass		0ms					
Battery							
Battery Voltage		2*96 VDC or 2*120VDC selectable		2*192 VDC or 2*240VDC selectable			
Battery Number		2*8PCS or 2*10PCS selectable		2*16PCS or 2*20PCS selectable			
Environment							
Ambient temperature		0°C ~ 50°C (Derating 50% above 40°C)					
Relative humidity		0 ~ 95%(no condensing)					
Operating altitude		<4000m(Derating use above 1km)					
Storage temperature (with battery)		-15°C ~ 40°C					
Storage temperature (without battery)		-25°C ~ 60°C					

Models	10K	10KS	15K	15KS	20K	20KS
Criterion						
Safety	IEC/EN 62040-1					
EMC	IEC/EN 62040-2					
Performance	IEC/EN 62040-3					

- (1) In CVCF mode or dual source input mode, UPS needs to be de-rated to 60% capacity for 1-1 mode (rated output power and maximum charging current).
- (2) @ 220VAC input phase voltage, rated output power and maximum charging.



SOLLATEK (UK) LIMITED

Sollatek House, Waterside Drive, Langley, Slough SL3
6EZ, United Kingdom

Tel: +44 (1753) 214 500

Email: sales@sollatek.com

Web: www.sollatek.com